




Read the corresponding technical documentation for handling and safety reasons.

Installation



Ensure that the capillary ends are flat and even.

1. Push the capillary through the head of the nut ①.
2. Attach the ferrule ②.



3. Fasten the capillary at the flow cell ③ fingertight.

